



Print Setup Guide

Canon | macOS

Follow the steps below to connect your Mac to the Canon copier over the network. In most cases, no driver download is needed.

Step 1: Add the Printer in Settings

macOS can connect to the copier directly using AirPrint. Follow the steps below to add it.

1. Open **System Settings** and go to **Printers & Scanners**.
 2. Click **Add Printer, Scanner, or Fax...**
 3. Switch to the **IP** tab (indicated by a globe icon).
 4. Enter the copier's IP address in the **Address** field.
*To find the IP address: On the copier's home screen, tap the **123** icon and look for the IP address on the main line.*
 5. Set the **Protocol** to **AirPrint**.
 6. Click **Add**.
 7. To rename the printer, click on it in your Printers & Scanners list and go to **Options & Supplies**.
-

(Optional) Step 2: Download the Print Driver

If the printer is not discovered automatically or additional features are needed, you can manually install the Canon UFR II driver.

1. Open a web browser and go to usa.canon.com.
 2. Search for **drivers** using the site search.
 3. Search for your **model number** in the driver search field and select it from the dropdown.
 4. Scroll to **Software and Driver Results** and download the **UFR II** driver.
 5. Open the downloaded **.dmg** file and follow the install wizard to complete the installation.
Note: You may need your computer password or Admin credentials at this step. If Admin credentials are required, please contact your IT administrator for assistance.
-

Admin Password Assistance

If you require Admin credentials at any point during setup, please contact your IT administrator for assistance.

Need Help?

*If you have trouble connecting or need assistance, please don't hesitate to reach out to us!
770-218-2020 or service@aomcopy.com*